

CZ**SADA FORCE PIKADO PRO OPRAVU BEZDUŠOVÝCH PLÁŠŤŮ****Návod k použití:**

1. Vyjměte ostrý předmět z dezénu pláště
2. Čistící jehlou upravte otvor po defektu
3. Vložte opravný knot jeho polovinou do provlékací jehly
4. Poté vyjměte provlékací jehlu a dohustěte plášť
5. Poznámka: je-li směr defektu šikmý, opravný knot vkládejte také šikmo

Sada obsahuje:

- 1 x jehlu čistící (průměr 3,85 mm x délka 38 mm)
- 1 x jehlu provlékací (průměr v nejširším místě 4,22 mm x délka 36 mm)
- 4 x knot - černý (průměr 1,5 mm x délka 60 mm)
- délka složené sady: 106 mm
- hmotnost: 24 g

EN**SET FORCE PIKADO FOR TUBELESS TIRES REPAIR****Instruction manual:**

1. Find and remove item that caused puncture in tire.
2. Push reamer tool into the puncture hole and move up and down until reamer tool moves easily in the hole.
3. Put seal/rubber plug in plug instal tool.
4. Then pull plug instal tool out slowly. Inflate the tire then.
5. Please note: If the direction of puncture hole is oblique, seal rubber plug should be inserted obliquely.

Set contains:

- 1 x reamer tool
(thickness 3,85 mm x length 38 mm)
- 1 x plug instal tool (thickness in
widest part 4,22 mm x length 36 mm)
- 4 x tire replacement plug-string,
black (thickness 1,5 mm x length 60 mm)
- length of assembled set: 106 mm
- weight: 24 g

